

1. There's 4 nail on the window frame.
Please remember where the position is.



2. Put the screen on the frame



3. Push the screen on the nail position to make the screen in.



To against the screen came away , there is a little tie when you push the screen in.

Make sure the screen into frame.



Man Ship

Australian Distributor: DeckHardware

www.deckhardware.com.au

02 9905 9400