
## **Man Ship**

Australian Distributor: DeckHardware www.deckhardware.com.au 02 9905 9400

## OPENING PORTS FOR STEEL BOAT



## INSTALLATION:

- 1. DIG HOLE PER THE SPECIFICATION FOR CUT OUT SIZE OF PORTLIGHT IN HULL WALL.
- 2. TO PUT PORTLIGHT INTO HULL PROPERLY THEN WELDING.
- 3. FULL FILL SEAL COMPOUND BETWEEN HULL & DECORATION MATERIAL TO PREVENT WATER LEAKING.